



PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
8618	BODY ASSEMBLY includes the following	8624	RETAINING RING
8611	BODY	8634	DIFFUSER ASSEMBLY includes the following
8616	TRIP SHAFT	8635	DIFFUSER BRACKET
8619	ARM (anti-backsplash WWSC nameplate)	8636	SPRING DIFFUSER
7120	ARM SPRING	8637	SCREW
6496	FULCRUM PIN	8639	SCREW SELF TAPPING
6494	ARM HOOD	8625	FEMALE BEARING ASSEMBLY includes the 7156 SLEEVE BEARING and
6495	SPACER WASHER	7117	NIPPLE BEARING
8614	UPPER TRIP	8731	TOP BEARING WASHER (white)
7705	TRIP SPRING	7102	BRASS WASHER
8621	LOWER TRIP ASSEMBLY includes the following	8738	BEARING SPRING
8615	LOWER TRIP SPRING	7157	BOTTOM BEARING WASHER (green)
7707	DETENT SPRING	7101	SEAL WASHER (black)
7708	DETENT BALL	8626	STOP COLLAR
8622	TRIP SLIP PIN	8806	MALE BEARING ASSEMBLY option of the above assembly except using 7158 SLEEVE BEARING
8621-012	RETAINING RING		
8623-002	WASHER		